

STRUCTURE OF THE MICROCARD

```

A02 = Special features/— 1
test speci-
fications
A01 = Structure of
microcard —A— **XXX XX*XX XXXXX XX
B01 = 2 —B— *XXXX XXXXX XXXXX XXXXX XXXXX XXX
C— XXXXX XXXXX XXXXX XXXXX XXXXX XXX
D— XXXXX XXXXX XXXXX XXXXX XXXXX XXX
E— XXXXX XXXXX XXXXX XXXXX XXXXX XX
F—
G—
H—
J—
K—
L—
M—
N—
XX*
12345 67890 12345 67890 12345 678
1 2

```

N28 = Table of contents and publication information

1 = Tools and devices

2 = Complete instructions, divided into test steps (no references)

a. Read from left to right.

b. Title of micropicture (appears on each coordinate).

E16	Product/component/test step	
-----	-----------------------------	--

Coordinate

c. Limits of section

Beginning

Mid-section

End

One-page section

A01	VERZEICHNIS DER PRÜFWERTE	=> <=
-----	---------------------------	-------

1. GENERAL

The test specifications given on this microcard are specially geared to the distributor test bench ZVS 50 (0 683 400 200) and the ignition-distributor test adapter KDZV 7202.


They are not to be used for other tests.

The correct test specifications for the corresponding ignition distributor can only be determined via the microcard "List of Test Specifications" W-001/016.

2. SPECIAL FEATURES

Special clamping flanges and drivers are required for various ignition distributors, so as to ensure proper testing (avoidance of damage).

In this microcard the clamping flange and driver are listed below the test specifications.




0 237 504 007

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 504 008

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 504 009

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 507 002

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 507 004

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 IL-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 507 006

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 4 = Gauge pressure
- 5 = Negative gauge pressure (vacuum) advance
- 7 = Gauge pressure (advance/retard)

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 507 007 / 008

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 4 = Gauge pressure
- 5 = Negative gauge pressure (vacuum) advance
- 7 = Gauge pressure (advance/retard)

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500



0 237 600 055

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-I


Sensor resistance 690...940 Ω

Air gap min. 0,1 mm

Tolerance-band allowance $\pm 0.5^\circ$ DS

Cut-out speed of limiter 3190 up to 3380 min⁻¹

Repair and test instructions W-237/503




0 237 601 001

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Cut-out speed of limiter 3230 up to 3430 min⁻¹

Repair and test instructions W-237/502




0 237 601 004

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 005

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 008

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	900...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS
Date of manufacture	-> 549

Repair and test instructions W-237/502




0 237 601 008

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS
Date of manufacture	550 ->

Repair and test instructions W-237/502




0 237 601 009

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 010

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions	W-237/502
------------------------------	-----------




0 237 601 011

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions	W-237/502
------------------------------	-----------




0 237 601 012

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 051

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 052

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 053

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 054

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 055

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Cut-out speed of limiter 3190 up to 3380 min⁻¹

Repair and test instructions W-237/502




0 237 601 056

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202	ID-I
Sensor resistance	900...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 057

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 002 109

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	± 0.5° DS

Repair and test instructions	W-237/502
------------------------------	-----------

Clamping flange	1 685 700 135
Driver	1 686 490 037




0 237 002 116

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	505...680 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	± 0.5° DS

Repair and test instructions	W-237/502
------------------------------	-----------




0 237 002 121

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 002 123

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 002 124 / 125

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 505...680 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 002 126

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 255...470 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 002 128

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502

Clamping flange 1 685 700 135
 Driver 1 686 490 037




0 237 002 129

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502

Clamping flange 1 685 700 135
 Driver 1 686 490 037




0 237 002 130

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 002 133

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 032

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 035

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 920...1200 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 049

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 050

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 051

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 052

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 054

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions	W-237/502
------------------------------	-----------




0 237 009 055

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions	W-237/502
------------------------------	-----------




0 237 009 056

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 057

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 059

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 061

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 062

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 063

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 064

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	± 0.5° DS

Repair and test instructions W-237/502




0 237 009 065

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	± 0.5° DS

Repair and test instructions W-237/502




0 237 009 066

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 067

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502

Clamping flange 1 685 700 135
 Driver 1 686 490 037




0 237 009 068

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 069

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 072

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	520...700 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 601

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS
Date of manufacture	686 ->

Repair and test instructions W-237/502




0 237 009 601

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS
 Date of manufacture -> 586

Repair and test instructions W-237/502




0 237 009 602

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 603

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 604

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 605

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 607

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 609

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions	W-237/502
------------------------------	-----------




0 237 009 610

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions	W-237/502
------------------------------	-----------




0 237 009 611

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^{\circ}$ DS

Repair and test instructions W-237/502




0 237 009 612

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^{\circ}$ DS

Repair and test instructions W-237/502




0 237 009 613

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 614

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 615

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,40 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 616

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 618

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 953

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 010 005 / 006

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-I
 Sensor resistance 905...1300 Ω
 Air gap min. 0,22 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 014 002

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 505...680 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Cut-out speed of limiter 2940 up to 3120 min⁻¹

Repair and test instructions W-237/502




0 237 020 137 / 138

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 020 140 / 141

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 020 162 / 163

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 020 166

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 020 167

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 020 168

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500

Clamping flange 1 685 700 117
Driver 1 686 400 007




0 237 020 169 / 170

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500





0 237 020 171 / 172


- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500






0 237 020 175 / 176

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 020 177 / 178

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500



0 237 020 179


- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500

Clamping flange 1 685 700 117
Driver 1 686 400 007




0 237 020 180 / 181

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Note:
Assess centrifugal-advance curve with decreasing speed.

Repair and test instructions W-237/500



0 237 021 047 / 048


1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500

Clamping flange 1 685 720 217
 Driver 1 686 400 007
 + Reduction 1 680 220 056




0 237 022 060 / 061

1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance
 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 030 015 / 016

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Cut-out speed of limiter 3280 up to 3480 min⁻¹

Repair and test instructions W-237/500




0 237 030 017 / 018

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Date of manufacture 545 ->
 Cut-out speed of limiter 3280 up to 3480 min⁻¹

Repair and test instructions W-237/500




0 237 030 019 / 020

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 030 023 / 024

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS
Cut-out speed of limiter 3280 up to 3480 min^{-1}

Repair and test instructions W-237/500




0 237 320 009

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/501




0 237 322 002

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/501



0 237 030 025 / 026

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance


Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Repair and test instructions W-237/500



0 237 031 021 / 022

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Date of manufacture \rightarrow 544
 Cut-out speed of limiter 3280 up to 3480 min $^{-1}$
 Repair and test instructions W-237/500




0 237 031 025 / 026

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-H
Tolerance-band allowance	$\pm 0.5^\circ$ DS
Cut-out speed of limiter	3280 up to 3480 min ⁻¹

Repair and test instructions	W-237/500
------------------------------	-----------




0 237 031 027 / 028

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-H
Tolerance-band allowance	$\pm 0.5^\circ$ DS
Date of manufacture	545 ->
Cut-out speed of limiter	3280 up to 3480 min ⁻¹

Repair and test instructions	W-237/500
------------------------------	-----------




0 237 031 029 / 030

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Cut-out speed of limiter 3280 up to 3480 min⁻¹

Repair and test instructions W-237/500




0 237 038 005 / 006

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Cut-out speed 1470 up to 1560 min⁻¹

Repair and test instructions W-237/500




0 237 038 007 / 008

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Cut-out speed 3280 up to 3480 min⁻¹

Repair and test instructions W-237/500




0 237 304 032

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 040 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/503

Clamping flange 1 685 720 214
 Driver 1 686 400 003



0 237 304 033

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard



Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,40 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Note:
 Double vacuum unit attached in retard position;
 retard has priority. In the case of advance there
 must be no vacuum in the vacuum retard unit.

Repair and test
 instructions W-237/503

Clamping flange 1 685 720 214
 Driver 1 686 400 003

D23 PRÜFWERTE (105)



0 237 304 034


- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard


Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,40 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test
 instructions W-237/503

Clamping flange 1 685 720 214
 Driver 1 686 400 003

D24 PRÜFWERTE (106)






0 237 304 035

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	0,40 mm
Tolerance-band allowance	± 0.5° DS
Cut-out speed of limiter	3140 up to 3330 min⁻¹

Repair and test instructions W-237/503

Clamping flange	1 685 720 214
Driver	1 686 400 003




0 237 304 036

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202	ID-I
Sensor resistance	950...1300 Ω
Air gap min.	040 mm
Tolerance-band allowance	± 0.5° DS

Repair and test instructions W-237/503


Clamping flange	1 685 720 214
Driver	1 686 400 003



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/501



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 601 013

1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 601 014

1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance
 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 505...680 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 950...1300 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS


Repair and test instructions W-237/502



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance ± 0.5° DS

Repair and test instructions W-237/502




0 237 009 073

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	505...680 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 086

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	270...385 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 087

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/502




0 237 009 089

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 505...680 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



- 1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-I
 Sensor resistance 270...385 Ω
 Air gap min. 0,25 mm
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/502



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/500



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS
 Date of manufacture 243-
 Cut-out speed of limiter 1555 up to 1650 min⁻¹


Repair and test instructions W-237/500



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/500



1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
 Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




1 = Distributor-shaft speed
 2 = Distributor-shaft adjustment
 3 = Negative gauge pressure (vacuum)
 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/500



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/500



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/500



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS


Repair and test instructions W-237/500



- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 021 053

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 021 064 / 065

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 022 053 / 054

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 022 068 / 069

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance
- 6 = Negative gauge pressure (vacuum) retard

Test adapter KDZV 7202 ID-H
Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500




0 237 301 018

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	520...700 Ω
Air gap min.	040 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS
Cut-out speed of limiter	2890 up to 3070 min $^{-1}$

Repair and test instructions W-237/503




0 237 301 019

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 5 = Negative gauge pressure (vacuum) advance

Test adapter KDZV 7202	ID-I
Sensor resistance	520...700 Ω
Air gap min.	0,25 mm
Tolerance-band allowance	$\pm 0.5^\circ$ DS
Cut-out speed of limiter	2890 up to 3070 min $^{-1}$

Repair and test instructions W-237/503



0 237 507 010

- 1 = Distributor-shaft speed
- 2 = Distributor-shaft adjustment
- 3 = Negative gauge pressure (vacuum)
- 4 = Gauge pressure
- 5 = Negative gauge pressure (vacuum) advance
- 7 = Gauge pressure (advance/retard)

Test adapter KDZV 7202 ID-H

Tolerance-band allowance $\pm 0.5^\circ$ DS

Repair and test instructions W-237/500

For production reasons:
continued on the following
coordinate.

TABLE OF CONTENTS

Section	Coordinates
Structure of this microcard.....	A01
1. General.....	A02
2. Special features.....	A02
3. Test specifications	

Part nos. of ignition distributors	MD	Coordinates
0 237 002 109		A27
116		A28
121		B01
123		B02
124 / 125		B03
126		B04
128		B05
129		B06
130		B07
133		B08
134/135		E08
009 032		B09
035		B10
049		B11
050		B12
051		B13
052		B14
054		B15
055		B16
056		B17
057		B18
059		B19
061		B20
062		B21

TABLE OF CONTENTS (CONTINUED)

Part nos. of ignition distributors	MD	Coordinates
0 237 009 068		B27
069		B28
070		C01
071		C02
072		C03
073		E09
086		E10
087		E11
089		E12
601	686->	C04
601	->586	C05
602		C06
603		C07
604		C08
605		C09
607		C10
609		C11
610		C12
611		C13
612		C14
613		C15
614		C16
615		C17
616		C18
618		C19
620		E13
621		E14
622		E15
623		E16
624		E17
625		E18
953		C20
0 237 010 005 / 006		C21
014 002		C22
020 137 / 138		C23
140 / 141		C24
150		E19
152		E20
158		E21

TABLE OF CONTENTS (CONTINUED)

Part nos. of ignition distributors	MD	Coordinates
0 237 020 162 / 163		C25
166		C26
167		C27
168		C28
169 / 170		D01
171 / 172		D02
173		D03
174		D04
175 / 176		D05
177 / 178		D06
179		D07
180 / 181		D08
188		E22
196		E23
204/205		E24
206/207		E25
021 045		E26
046		E27
047 / 048		D09
051		E28
053		F01
064/065		F02
022 053 / 054		F03
060 / 061		D10
068 / 069		F04
030 015 / 016		D11
017 / 018	545->	D12
019 / 020		D13
023 / 024		D14
025 / 026		D15

TABLE OF CONTENTS (CONTINUED)

Part nos. of ignition distributors	MD	Coordinates
0 237 020 021 / 022	->544	D16
025 / 026		D17
027 / 028	545->	D18
029 / 030		D19
038 005 / 006		D20
007 / 008		D21
301 018		F05
019		F06
304 032		D22
033		D23
034		D24
035		D25
036		D26
320 009		D27
322 002		D28
503 005		E01

TABLE OF CONTENTS (CONTINUED)

Part nos. of ignition distributors	MD	Coordinates
0 237 504 006		E02
007		A03
008		A04
009		A05
507 002		A06
004		A07
006		A08
007/008		A09
010		F07
600 055		A10
601 001		A11
004		A12
005		A13
008	→549	A14
008	550→	A15
009		A16
010		A17
011		A18
012		A19
013		E03
014		E04
015		E05
017		E06
051		A20
052		A21
053		A22
054		A23
055		A24
056		A25
057		A26
058		E07

PUBLICATION INFORMATION

(C) 1991 ROBERT BOSCH GmbH Automotive Equipment -
 After-Sales Service, Department of Technical
 Publications KH/VDT, Postfach 10 60 50,
 D-7000 Stuttgart 10.
 Published by: After-Sales Service Department for Training
 and Technology (KH/VSK).
 Press date 03.1991.
 Please direct questions and comments concerning the
 contents to our authorized representative in your country.
 This publication is only for the use of the Bosch After-
 Sales Service Organization and may not be passed on to
 third parties.

Microfilmed in the Federal Republic of Germany.
 Microphotographié en République Fédérale d'Allemagne.